



## **MagWall-Lite with Permanent Adhesive Installation Instructions**

1. Be sure the surface you are going to apply the dry-erase to is smooth and clean
2. Unroll the Dry-Erase face down on a large table or the floor. Start to peel away the paper back evenly across the short direction. It works well if you roll it up as you peel, this will ensure that it will not rip.
3. Using a spray bottle lightly wet the entire area you are going to install the whiteboard. You can add 3 drops of liquid soap to the bottle of water for better performance.
4. Carefully pick up making sure that the sticky surfaces do not come into contact with each other. Hold the top edge and press a 6" strip across the top to hold the film in place. This will allow you to pull down on the bottom corners and slowly stick the product from the top down working out any bubbles. You will be able to use a squeegee or an old credit card to work out the bubbles. Allow to dry over night before use.
5. After the Dry-Erase is mounted you can trim this to the inside of a chalkboard frame with a razor knife.
6. When you want to remove the dry-erase, it may take paint off the wall and may come off in pieces.

NOTE: Material should not be used where seams are needed. There is no factory edge on material. Adhesive is very aggressive so it is difficult to get bubbles out. Material can be used for resurfacing chalkboards where the material is put on the board and then the edges are trimmed to fit the board. Material is a low price alternative but you are on your own for the installation. If you have an application where there will be seams please go to the Mag-Wall-II, our wallpaper backed material. This adhesive can tear the dry wall down when moved during installation leaving an uneven surface to install on.