

j-cap:

- 1) Examine trim to assure quantity and quality is as ordered. The installer must supply the adhesive to adhere the **j-cap** and drywall compound. The adhesive used to adhere the **j-cap** should be a craft-type contact cement or a 1/2" double-faced film tape.
- 2) With a pencil, lightly mark the perimeter of the area to receive the trim and wallcovering on the wall.
- 3) Measure and cut the trim to size using a miter saw with a carbide tip blade. Cut the ends of each piece to a 45° angle. The longest leg of the trim will face the new wallcovering side.
- 4) Apply craft-type contact adhesive or double-faced tape to the backside of the longest leg and adhere to the wall. Follow the manufacturer's directions.
- 5) With a broad knife, feather drywall compound to the highest point on the long leg of the trim. See graphic.
- 6) Follow wallcovering installation instructions. For best results, apply wallcovering; trim the wallcovering, leaving approximately 1/8" extra material around the perimeter; and tuck exposed edges into the 1/16" opening.

Profile View

